

Printer settings For your DF sails

Save the PDF(s) to your computer. Be sure to open in Adobe Reader not another viewer.

- Hit the Adobe Print button and you should see a window like below.
- Page Sizing & Handling section is where you need to make changes
- Push poster button.
- Tile Scale should be 100%
- Overlap should work at default setting 0.005
- Check the box next to – Cut marks (you will use these to put the sheets together)
- In the preview you can see the sheet layout.
- Your ready, hit the print button in the lower right.

